

paintistanbul
TURKCOAT
CONGRESS

dyo

Effect Of Different Mfft Values On Fire Resistance Time In Water Based Intumescent Coatings

paintistanbul & TURKCOAT CONGRESS, 2023

Technical presentation – Ferdi ESER, Duygu ERDEM

Passive Fire Protection for Structural Steel


Passive Fire
Protections allows Safe
Escape

→ Passive Fire Protection (PFP) prevents structural collapse and allows safe escape in combination with active fire protection

→ Prevents collapse between 30 minutes to 180 minutes depending on the building type.



Passive Fire Protection has several methods for providing fire resistances to structural steels



Fire Curve for Cellulosic Fire and Hydrocarbon Fires

European regulations and guidelines

European Technical Assessments (ETA) defines the ‘Reactive Coatings for Fire Protection of Steel’ in **EAD 350402-00-1106** since 2017. According to regions, regulations can change.


Product Group	Description	European Standards	European Product Standards or EADs	North American Requirements	British Standards
Structural steel members (including the contribution of the applied protection)	Reactive protection to steel members	EN 1365 EN 13381-8	ETAG 018 EAD 350402-00-1106	UL 263 UL 1709 ASTM E119	BS 476: Part 21& ASFP Yellow Book 5th Edition

Intumescent Coatings

Passive Fire Protection for Structural Steel


During the Fire,
Environment
Temperature reaches to
the 1050 °C during 120
minutes

- In cellulosic fires, in 4-5 minutes, **Environment Temperature** reaches to 550 °C which is the general critical temperatures for steel structures.
- During the fire, **Environment Temperature** reaches to more than 1000 ° C degree after 60 minutes acc. to ISO 834-1 Fire curve.
- Passive Fire Protection ignores to reaching of critical temperature of steel structure (i.e. 450, 500, 550 or 600° C degree) and **expands the fire resistance** time till 180 minutes.



Time (min)	0	15	30	60	120	180	240	300	360
Environment Temperature (°C)	23	739	842	945	1050	1110	1150	1185	1215

Steel structures has very poor thermal conductivity performance and deliver its thermal energy to the conducted structures.





Fire Curve Differences of Coated and Uncoated Steel and Critical Temperature

Intumescent Coatings

Passive Fire Protection for Structural Steel

Steel does not burn but has serious weakness

- Strength factor decreases with rising temperature
- Reaching to 0.6 Strength Factor at Critical Temperature, steel losses its %40 strength and does not carry the building anymore.




Intumescent Coatings is one of the passive fire resistances method that requires aesthetics view to structures.

Intumescent Coatings

Passive Fire Protection for Structural Steel

Commercial intumescent coatings are usually applied in a 3 coat system



Under the influence of fire, the intumescent coating swells in a controlled manner to produce an insulating foam that protects the substrate from the effects of the fire and delays temperature increase



Unlike cementitious sprays or mineral boards, thin coatings preserve the aesthetics of the steel structure



Intumescent Coatings

Passive Fire Protection for Structural Steel



With an increased use of steel structures in construction, architects want to preserve the steel aesthetic of buildings



This has allowed **intumescent coatings to dominate the passive fire protection market** over the past decade

- It is possible to have decorative intumescent coatings
- Only intumescent coating can cover complex shapes
- They can repair easily if damaged



European regulations and guidelines

EAD (European Assessment Document) 350402-00-1106 Standard covers the;

- Durability performance of the coating
- Coating system such as primer and top coat (if need),
- Standart for Fire resistance assessment


Type	Exposure Description
X	Renderings and rendering kits intended for all climatic conditions (internal, semi-exposed and exposed to weather)
Y	Renderings and rendering kits intended for internal and semi-exposed conditions. "Semi-exposed" includes temperatures below 0°C, but no exposure to rain and limited or casual exposure to UV (but the effect of UV exposure is not assessed.)
Z1	Renderings and rendering kits intended for internal conditions with humidity equal to or higher than 85% RH, excluding temperatures below 0°C.
Z2	Renderings and rendering kits intended for internal conditions with humidity lower than 85% RH, excluding temperatures below 0°C.

Intumescent Coating Components

Mineral Acid Source

Ex. Ammonium Polyphosphate

- Catalyst
- Contains high amount of phosphorous
- Decomposes to phosphoric acid with heat decomposition
- Decomposition starts around 250 °C and finishes around 600°C



Ammonium polyphosphate

Source of Carbon

Ex: Pentaerythritol

- Carbonific
- Polyhidric alcohol
- Decomposition starts between 220°C and 260°C




Pentaerythritol

Blowing Agent

Ex: Melamine

- Spumific
- Decomposition product
- Ex: melamine



Melamine

Binder is also a key element of the formulation

Intumescent Coatings

Thermal Analysis Stages

→ Stability Stage (20 – 230 °C) : The main lost components are volatilized solvents. Nearly 170°C, resin that melts and softens absorbs the energy.

→ Formation of Char Layer Stage (230-450°C) :

- Acid source began to decompose at about 260°C.
- 280-350°C blowing agent decomposes and gave our large quantities nono-flammable gases.
- This cause to formation of a carbon-like foam layer over the substrate.

Carbon source dehydrated by acid attack through an esterification at 320-360°C.


→ Stage of Char Loss (455 – 760 °C) : Char layer caused to the heat absorbtion. Network density between char layer and nano-particles increased. Cross-linkings increase and this helps to more absortion of heat.

→ Formation of Inorganic Layer (760 - 1000 °C) : After burning, only char and inorganic retains. Their reaction helps to create more thermal barrier.



dyo

Post heating



Intumescent Coatings

Char Formation



Intumescent coated steel	Char Formation	Foam formation	Solidification
Application on steel structure	Binder softs and melts	Fast carbonization and inert gas formation	Oxidation of C to CO or CO ₂
Suitable as Exterior: X and Y condition	Polyphosphoric acid releases	Blowing agent decomposition	Mechanical strenght creates by crosslink steps
Suitable as Interior: Y, Z1 and Z2 Condition (Generally water based)	Reaction with OH agent and char forms	Heat Insulation barrier created	Thermal barrier structure via combined with TiO ₂

Intumescent Coatings


Intumescent Coating Components

Although binder is mentioned less in the literature, its role is undoubtedly important.

- Eco friendly binder (especially water based) and less carbon foot print is preferred
- Generally Poly(vinylacetate) types binder

Function of Binder

- Key component for Minimum Film Forming Temperature (MFFT)
- Permits foam structure, correct binder type and ratio permits uniform foam structure
- Good adhesion to surface
- Important for application conditions Determines application rheology
- Require optimum viscosity and helpful to get high thickness in one coat application



Poly(vinylacetate)

Binder should have available enough solid content and elasticity that let to creates foam structure



Swelling of Intumescent Coatings

Swelling of the Intumescent product is very important to get good heat insulation and integrity.

- Good swelling property helps to achieve high thermal performance in the char.
- Cracks can cause to release inert gases that major swelling component to the out of the char.

Importance of Char Elasticity

- Decrease hardness of the char
- Minimize the cracks and develops the integrity
- Eliminate the exit of inert gases out of to the char
- Maximum swelling property



MFFT of the Intumescent product is important to get high char elasticity

Intumescent Coatings

MFFT on Fire Resistance

Mfft plays a bit different roles in fire resistance products.

- Minimize the holes and helps to get uniform dry film surface
- Reduce the crack observation and requires to good swelling of char
- Assist to smooth surface on char during the fire
- Long fire resistance time




Intumescent Coatings

Relationship between char elasticity and binder type

It is known that Vinyl acetate co-polymers has lower MFFT values than Acrylate or Styrene acrylate co-polymers. To achieve lower MFFT, correct binder should choose.

- In this study, the fire resistance performances of products with MFFT values of 15°C, 5°C and 2°C were examined to increase char flexibility
- Mechanical strenght of char is determined to compare their softness and hardness of the char
- Swelling volume is calculated
- Crack observations are examined
- Uniform foam structure (fluffy, compact or fully compact) char formation is observed




Intumescent Coatings In-House Test Method

In this study, in-house test method that include electrical furnace is developed

→ The study does not represent the industrial furnaces but it can be helpful guide for next studies. Dont forget that the method can include some deficiencies.

→ This method can be used to compare



Electrical Furnace (min)	15	30	45	60	120	180
Industrial Furnace (min)	10	20	30	40	80	120

180 minutes of fire resistance in Electrical Furnace is equal to 120 minutes fire resistance in Industrial Furnaces.

Intumescent Coating Components

Stable In-House Test Method offers advantages as

- to compare the correct raw material chosen
- to determine the performance of competitive product and own formulation

ISO 834 Fire Curve

$$T_f = 345 * \log_{10}(8t+1) + 20$$


- T_f is Final Temperature as celcius degree,
- t is time as minute



Intumescent Coatings


MFFT on Fire Resistance

The measurement of MFFT results are found as 15°C, 5°C and 2°C degree. The samples are applied on steel substrate as ~1000 micron dry film thickness (DFT). König Pendulum value of steel substrates that applied intumescent product are controlled to check same order as MFFT.



Intumescent Coatings




Swelling and Crush Test In-House Test Method Results*



*R.J.Mcnamee, K. Storesund, R.Stolen, *The Function of Intumescent Paint for Steel during Different Fire Exposures*, SP Sveriges Tekniska Foreskningsinstitut, 2016




Intumescent Coatings

Swelling and Crush Test In-House Test Method Results

PERFORMANCE	15 °C MFFT	5 °C MFFT	2 °C MFFT
SWELLING VISUAL	 A photograph showing a dark, charred, and swollen intumescent coating sample. The sample is relatively flat and compact. A vertical ruler is placed to the right of the sample for scale, showing it is approximately 35 mm thick.	 A photograph showing a dark, charred, and swollen intumescent coating sample. The sample is significantly more expanded and porous than the 15 °C sample. A vertical ruler is placed to the right of the sample for scale, showing it is approximately 95 mm thick.	 A photograph showing a dark, charred, and swollen intumescent coating sample. The sample is highly expanded and porous, appearing as a large, irregular mass. A vertical ruler is placed to the right of the sample for scale, showing it is approximately 105 mm thick.
DRY FILM THICKNESS (DFT)	1 mm	1 mm	1 mm
THICKNESS OF SWELLING	35 mm	95 mm	105 mm
MECHANICAL STRENGTH	10,6 N	9,1 N	7,6 N

Intumescent Coatings

Fire Resistance In-House Test Method Results

PERFORMANCE	15 °C MFFT	5 °C MFFT	2 °C MFFT
CRACK and POROSITY OBSERVATION			
UNIFORM FOAM STRUCTURE	Non-uniform swelling with different bubble diameter	Compact swelling	Fully compact swelling

Intumescent Coatings Results




PERFORMANCE	15 °C MFFT	5 °C MFFT	2 °C MFFT
FIRE RESISTANCE GRAPH	<p>The graph plots Steel Temperature (°C) on the y-axis (0 to 1400) against Fire Resistance Time (min) on the x-axis (0 to 300). A horizontal dashed red line at 500°C is labeled 'Critical Temperature'. Four curves are shown: 2°C MFFT (blue), 5°C MFFT (yellow), 15°C MFFT (red), and ISO 834-1 FIRE CURVE (grey). The 2°C MFFT curve reaches the critical temperature at approximately 192 minutes. The 5°C MFFT curve reaches it at approximately 187 minutes. The 15°C MFFT curve reaches it at approximately 171 minutes. The ISO 834-1 FIRE CURVE reaches it at approximately 171 minutes.</p>		
FIRE RESISTANCE TIME	171 min	187 min	192 min

Intumescent Coatings

Summary

By decreasing MFFT on paint; results are achieved in below;

- Film porosity in char layer decreased at low MFFT values
- Film hardness decreased. As a result of this, cracking tendency decreased.
- Releases of inert gases avoided and this helped to insulation foam formation.
- Finally, Fire resistance time is increased.



1927' den bu yana..
"İlk Günkü Heyecanla"



Teşekkürler

